



Rackmount Faceplate Assembly Instructions

Assembling the rackmount faceplate that comes with your Inteset Thin mini-ITX Case couldn't be easier. You can mount either one or two cases to this faceplate.

1. Open the package that contains the faceplate.
2. Remove the faceplate from the package and carefully remove the packaging so as not to scratch the anodized aluminum surface.
3. Set up the case(s) that are to be attached to the double faceplate. The cases are shipped with the single faceplates attached.
4. Use 5/64th hex key to remove the single faceplate from your case(s).
5. Install the Plexiglas IR windows (provided) on the faceplate using a small amount of silicone in each corner of the indented area on the back of the faceplate.
6. Line up the double faceplate to the mounting holes on the case and thread the mounting screws into the same holes in the case from which they were removed.
7. Make the screws finger tight until all screws are in place.
8. Tighten the screws using a 5/64th hex key.
9. If you are only mounting a single case then mount the blank cover plate to fill in the space on the faceplate for the second case. Use the 4 machine bolts and nuts provided.

Rack mounting the case(s):

10. Carefully move the mounted case(s) into your rack giving them support with your hand or on a lower component in the rack.
11. Thread standard rackmount bolts (not provided) into the rack holes on each side. The cases will want to push the bottom of the faceplate out so tighten the lower bolts first using a #2 Phillips screwdriver.
12. Avoid putting any pressure on the back of the components after rackmount installation.

